







The 3 modes the tester shows now are:

- NON-VW BATT.TEST
- ORIG-VW-BATT.TEST
- STOCK MAINTANCE

Icon	Description
	Stock maintenance: For testing on batteries of stationary and stock vehicles, prior to delivery to the customer.
	Orig. VW battery Test / PAG original battery test: For testing of genuine Volkswagen/ Porsche batteries in all service works as well as within the scope of warranty processing.
	Non-VW battery Test / Non-PAG battery test: For testing of external batteries during service works.
	Enables you to view your stored test results and print them to the internal printer.
	Includes a test counter, data transfer utility and displays the tester software versions.
	Utilities, many of which customize your user interface in the tester.